



# MULTI FUNCTION AIR FRYER / HOB WITH DIGITAL DISPLAY



## USER GUIDE



Part No: HW1901 - BLACK  
Part No: HW1902 - GREY

## OPERATING MANUAL

## **BEFORE FIRST USE - UNPACKING YOUR MULTI AIR FRYER**

1. Remove the product and all packaging, including any stickers or labels.
2. Use only a damp cloth to wipe the body and interior of the product.
3. Use hot water and detergent to clean the fryer and basket, but do not use metallic or abrasive cloths. Allow all parts to dry.
4. Air fryers are heated by hot air. Do not pour oil, grease or other liquids into the fryer.
6. Do not overfill the air fryer as this will block airflow and reduce cooking results.

## **IMPORTANT INSTRUCTIONS PLEASE READ CAREFULLY BEFORE USE.**


When using electrical appliances, basic safety precautions should always be followed, including the following.

1. Do not touch hot surfaces directly.
2. Do not operate this product with wet hands, immerse the cord, plug or body in water or other liquids to prevent electric shock. Do Not plug or unplug the power plug or operate the control panel with wet hands.
3. Keep this product and its power cord out of the reach of children.
4. Never leave the product unattended.
5. Never immerse the product in water to avoid electrical shock and damage to the product.
6. The appliance should be unplugged from the socket when not in use and before cleaning, and parts should be inserted or removed after cooling.
7. Do not operate the product if the power cord is damaged, the plug is damaged, or the appliance fails or is damaged in any other way.
8. For indoor use only. Not for commercial use.
9. When disconnecting, all switches should be turned to "OFF" and the plug should be unplugged.
10. Always use this product on a dry, stable and level surface.
11. Do not cover the air outlet and air inlet while the product is working.
12. Do not use this product on or near tablecloths, curtains or any other flammable materials.
13. Do not place the product close to the wall or other products, and leave at least 10cm of space on the sides, back and top. Do not place anything on top of the product.
14. When the product is working, hot air will come out of the air outlet, so for safety reasons, please stay away from the air outlet.
15. If black smoke comes out, please unplug the product immediately and do not take the fryer out until the product stops smoking..
16. This is **NOT** a toy, keep away from children..
17. Never try to repair the unit to avoid danger of electrical shock or fire.
18. You can wipe the body with a damp cloth and make sure the appliance is completely cool before cleaning.

## Use an extension cord

- A). The short power cord is provided to reduce the risk of being entangled or tripped by the long power cord.
- B). Extension cords can be used, but care must be taken when using them.
- C). If an extension cord is used:
  - 1). The power rating marked on the cord set or extension cord should be consistent with the power rating of the appliance;
  - 2). The power cord should be placed properly and should not hang over a counter or tabletop to prevent children from pulling it or accidentally tripping over it.

## Component Parts



### KEY

3. Frying basket	1. Heating gear	2. Decorative body
6. Base	4. Pot (fryer)	5. Flip control knob
	7. Pot lid	

## Instructions


**Tips:** Place this product on a flat, smooth, stable surface. Ideally place it on a heat-resistant surface.. This product has two working modes, one is air fryer mode and the other is frying/hob mode. With the fryer removed, press the rotation button and rotate the machine head 180 degrees to switch between air fryer mode and roasting/roasting mode.

**Note:** Do not touch the fryer or baking sheet immediately after cooking, or you may burn yourself and move the fryer by the handle.

1. Connect the power cord plug to a grounded socket.
2. Place the frying basket in the fryer.
3. Place the food on the fryer basket.
4. Place the fryer back into the air fryer.
5. Select the desired function on the control panel. You can set the cooking time and temperature manually.
6. Operate the control panel.

## Cooking Instructions

### First mode - Air Fryer Mode, the control panel as below:



1. When air fryer connecting electricity, machine will stay at standby mode.

Touch control panel button, entering work-standby mode, menu will be shown.

► The Time temperature light will start flashing on panel. Now touch the LED digital display and will change to show the temperature(200°C/400°F) and the time(16 min) which is preset.

You can touch "+" or "-" to set your temperature and time.

► Then touch and the air fryer will start working. You can also touch to pause cooking. The whole process is only to adjust temperature and time.

#### Adjusting the temperature

Touch one time is adjusting temperature, temperature range of adjustment is 40°C-200°C (105°F-400°F). Touch

"+" or "-" each time the temperature will increase or reduce 1°C/ 5°F.

If you press for a longer time, the temperature will change rapidly at a rate of 5°C/ 5°F.

#### Adjusting the time

Touch again will turn to adjust the time exchange. The adjustment of time is: 1- 60mins touch "+" or "-" each time. The time will increase or reduce per 1 minute. If you press longer, the time will change rapidly at a rate of 5 minutes.

#### Cooking instructions

*Air frying function default menu chart shown below.*



#### Note:

Cooking times vary depending on the weight of the food. The cooking times given in this chart are for reference only and should be adjusted according to quantity.

Menu	Icon	Temp (°C)	Time	Notes
Vegetables		150°C	4-16 min	
Pizza		160°C	8-12 min	
Beef		200°C	6-10 min	
Chicken wings		200°C	6-18 min	
Chips		160°C	12-16 min	

## Cooking Instructions

### Second mode - Grill Mode, the control panel as below:



1. When the air fryer is connected to power, the machine will stay at standby mode.

① Touch the on/off button and the work-standby mode menu will be all shown, and will begin flashing on the panel.

② Touch, LED digital display will inter change to show the temperature (230°C/450°F) and time(20min) which is preset. At this moment can press “+” or “-” to adjust the temperature and time.

- ▶ Touch and the hob will start to work.
- ▶ To pause working touch again. to adjust the time and temperature.

#### Adjusting the Temperature

① Touch one time for adjust temperature. The temperature range of adjustment is 40°C-230°C (105°F-400°F).

Each time you touch “+” or “-” the temperature will increase or decrease 1°C/ 5°F. If it pressed long, the temperature will change rapidly at a rate of 5°C/ 5°F.

#### Adjusting the Time

Touch it again will turn to adjusting the time. The adjustment of time is: 1-60 min touch “+” or “-” each time to increase or reduce by 1 minute. If pressed for longer, the time will change rapidly in increments of 5 minutes.

**Tips:** Food cooked in the fryer will look golden rather than black or brown. Discard overcooked parts and do not eat them. Do not cook fresh fries at temperatures above 200°C. If necessary, preheat the product with the fryer empty for 3 minutes, then place the food in the fryer and select the appropriate program.

Excess oil from cooking food will collect at the bottom of the fryer.

#### Special reminder:

Do not use metallic utensils in the **Grill mode!**

For better cooking results, you can remove the fryer by the handle during operation, place it on a heat-resistant platform, turn the food over, and then put it back into the device to continue cooking.

When the timer sounds, it means the cooking time is up. Take the frying basket out of the air fryer and check if the food is cooked. If not, put it back into the air fryer and set the timer to cook for a few more minutes.

**Note:** If you need to turn off the device manually, press the power button or unplug the power cord.

When the food is cooked, take out the fryer and pour the food into a dish.