Product Usage

This product helps to prevent and remove excess moisture in the home, motorhomes and caravans.


Helps to prevent mould and mildew from forming.

Mould and mildew are two of the most common problems of high moisture in the home. Placing a moisture absorber inside a room or space will help decrease the moisture in the air and as a result will help stop mould from forming. Excess moisture can have unpleasant effects. It can create a feeling of coldness and cause musty smells to form. This moisture absorber will help to reduce the excess moisture and protect your personal belongings such as clothes, furnishings etc.









Helps protect your personal belongings such as clothing, valuables, food and electronics etc, from damp and musty smells.

Components

- Moisture Absorber Body
- 2 Wet / Dry Silica Gel Display Window
- Moisture Absorbing Holes
- 4 Charging Indicator Light
- 6 Mains Plug Connection

Voltage	AC220-240V 50/60Hz
Power	25W
Net Weight	0.63KG
Size	W174×D50×H114mm
Hygroscopic Capacity	150ml





RECHARGEABLE MOISTURE ABSORBER PEBBLE

Part No: 11710



USER MANUAL

IMPORTANT INSTRUCTIONS PLEASE READ CAREFULLY BEFORE USE

- When using for the first time, if the silica gel in the display window is green please charge for 15-20 hours.
- This moisture absorber is ready for use when the silica gel in the display window has turned orange.
- After several days of use the silica gel will turn from orange to green as the moisture is absorbed. The moisture absorber will then need to be recharged.



Silica Gel Indicator which tells you when to recharge.

- Orange indicates Dry
- Green indicates Wet
- Indicator light
- Connect the power cord to the unit, plug into the mains socket and power on.
- The indicator light will come on and show that the unit is drying out the silica gel.
- After 15-20 hours the silica gel will have changed from green to orange and be ready to use again.
- If the silica gel has not returned back to orange then keep charging until it does.
- Remove the power cord from the unit and disconnect from the mains socket.
- The moisture absorber is now ready for use.



Mains Plug Connection



CAUTION AND SAFETY

- The rate of moisture absorption will depend on the amount of humidity and the temperature of the environment.
- This product must be kept away from all flammable objects. Please keep this product more than 10cms distance from all surroundings to increase the air convection and avoid product damage.
- It is normal to see steam on the display window when charging.

- DO NOT immerse this product in water as this could result in electric shock and damage to the product.
- DO NOT put this product near medical products and keep away from all gas and other flammable objects.
- Stop using this product if you notice any burning or peculiar smells. Disconnect immediately from the mains power.
- This is NOT a toy and must be kept away from children.