

PCB-147-MD INFORMATION

When using the new PCB-184-MD to replace an existing PCB-147-MD please use the below chart to relocate the terminals from PCB-147-MD to PCB-184-MD

PCB-147-MD	PCB-184-MD	CIRCUIT
P1	P2	ON/OFF MASTER SW
P2	P4	ON/OFF MASTER SW
P3	P1	FRIDGE NEG
P4	P5	NEG
P5	P6	PUMP RELAY (+VE COIL)
P6	P7	PUMP RELAY (COMMON)
P7	P8	PUMP RELAY (NO)
P8	P10	PERM (ALARM)
P9	P11	PERM (FRIDGE IGN+RADIO)
P10	P12	VAN BATTERY
P11	P15 (LINKED WITH P9)	CHARGER
P12	P14	FRIDGE POWER IN
P13	P13	FRIDGE POWER OUT
P14	P16	CAR BATTERY
P15	P17	LIGHTS 1
P16	P18	LIGHTS 2
P17	P19	IGNITERS (HOB)
P18	P20	PUMP/TOILET FEED
P19	P21	AUXILLARYS
P20	P22	RADIO FEED
P21	P23	ROOF FAN
P22	P24	FIRE
P23	P25	WATER HEATER

On PCB-184-MD P15 and P9 needs to be linked together before connecting to the charger unless using a dual stage charger.

LINK SUPPLIED WITH THE BOARD